

# Lecture

## Navigation Mathematics: Rotation Matrices

EE 570: Location and Navigation

Lecture Notes Update on January 26, 2016

Kevin Wedeward and Aly El-Osery, Electrical Engineering Dept., New Mexico Tech

In collaboration with

Stephen Bruder, Electrical & Computer Engineering, Embry-Riddle Aeronautical University

\_\_\_\_\_ .1

Lecture Topics

### Contents


1	Review	1
2	Attitude	2
3	Rotation Matrices	4
4	Examples	6
5	Summary	6

\_\_\_\_\_ .2

### 1 Review

Review


- Coordinate Frames - note subscript will "name" axes (vectors)
- Earth-Centered Inertial (ECI) Frame -  $i$
- Earth-Centered Earth-Fixed (ECEF) Frame -  $e$
- Navigation (Nav) Frame -  $n$
- Body Frame -  $b$



## 2 Attitude (Orientation)

### Attitude (Orientation)

- Attitude describes orientation of one coordinate frame with respect to another.
- How would one describe orientation of ECEF frame wrt/ECI frame at point in time when angular difference is  $\theta$ ?



-  $e$ -frame rotated away from  $i$ -frame by angle  $\theta$  about  $z_i \equiv z_e$

### Attitude (Orientation)

- Less obvious, but equally valid, way of describing  $e$ -frame wrt/ $i$ -frame is by giving coordinates of the  $e$ -frame's axes in the  $i$ -frame.
- Leads to need for further notation:


$$- x_e^i \text{ is } x_e = x_e^e = \begin{bmatrix} 1 \\ 0 \\ 0 \end{bmatrix} \text{ coordinatized (written wrt/) the } i\text{-frame}$$

$$- y_e^i \text{ is } y_e = y_e^e = \begin{bmatrix} 0 \\ 1 \\ 0 \end{bmatrix} \text{ coordinatized (written wrt/) the } i\text{-frame}$$

$$- z_e^i \text{ is } z_e = z_e^e = \begin{bmatrix} 0 \\ 0 \\ 1 \end{bmatrix} \text{ coordinatized (written wrt/) the } i\text{-frame}$$

### Attitude (Orientation)

- $x_e^i$ :




$$\bullet x_e^i = \begin{bmatrix} x_e \cdot x_i \\ x_e \cdot y_i \\ x_e \cdot z_i \end{bmatrix} = \begin{bmatrix} \|x_e\| \|x_i\| \cos(\theta) \\ \|x_e\| \|y_i\| \cos(90^\circ - \theta) \\ \|x_e\| \|z_i\| \cos(90^\circ) \end{bmatrix} = \begin{bmatrix} \cos(\theta) \\ \sin(\theta) \\ 0 \end{bmatrix}$$

.6

### Attitude (Orientation)

- $y_e^i$ :




$$\bullet y_e^i = \begin{bmatrix} y_e \cdot x_i \\ y_e \cdot y_i \\ y_e \cdot z_i \end{bmatrix} = \begin{bmatrix} \|y_e\| \|x_i\| \cos(90^\circ + \theta) \\ \|y_e\| \|y_i\| \cos(\theta) \\ \|y_e\| \|z_i\| \cos(90^\circ) \end{bmatrix} = \begin{bmatrix} -\sin(\theta) \\ \cos(\theta) \\ 0 \end{bmatrix}$$

.7

### Attitude (Orientation)

- $z_e^i$ :



$$\bullet z_e^i = \begin{bmatrix} z_e \cdot x_i \\ z_e \cdot y_i \\ z_e \cdot z_i \end{bmatrix} = \begin{bmatrix} \|z_e\| \|x_i\| \cos(90^\circ) \\ \|z_e\| \|y_i\| \cos(90^\circ) \\ \|z_e\| \|z_i\| \cos(0) \end{bmatrix} = \begin{bmatrix} 0 \\ 0 \\ 1 \end{bmatrix}$$

.8

## Attitude (Orientation)

- $3 \times 3$  matrix can be constructed by using each basis vector of the  $e$ -frame wrt/ $i$ -frame as a column

$$C_e^i = \begin{bmatrix} x_e^i & | & y_e^i & | & z_e^i \end{bmatrix} = \begin{bmatrix} \cos(\theta) & | & -\sin(\theta) & | & 0 \\ \sin(\theta) & | & \cos(\theta) & | & 0 \\ 0 & | & 0 & | & 1 \end{bmatrix}$$


- $C_e^i$  describes the attitude/orientation of the  $e$ -frame wrt the  $i$ -frame
- $C_e^i$  referred to as a rotation matrix, coordinate transformation matrix, or direct cosine matrix (DCM)

.9

## 3 Rotation Matrices

### Rotation Matrices

- In general, a rotation matrix  $C_2^1$  describes the orientation of **frame {2}** relative to **frame {1}**



$$\text{via } C_2^1 = [x_2^1, y_2^1, z_2^1] = \begin{bmatrix} x_2 \cdot x_1 & y_2 \cdot x_1 & z_2 \cdot x_1 \\ x_2 \cdot y_1 & y_2 \cdot y_1 & z_2 \cdot y_1 \\ x_2 \cdot z_1 & y_2 \cdot z_1 & z_2 \cdot z_1 \end{bmatrix}$$

.10

### Properties of Rotation Matrix

$$C_2^1 = [x_2^1, y_2^1, z_2^1] = \begin{bmatrix} x_2 \cdot x_1 & y_2 \cdot x_1 & z_2 \cdot x_1 \\ x_2 \cdot y_1 & y_2 \cdot y_1 & z_2 \cdot y_1 \\ x_2 \cdot z_1 & y_2 \cdot z_1 & z_2 \cdot z_1 \end{bmatrix} = \begin{bmatrix} x_1 \cdot x_2 & x_1 \cdot y_2 & x_1 \cdot z_2 \\ y_1 \cdot x_2 & y_1 \cdot y_2 & y_1 \cdot z_2 \\ z_1 \cdot x_2 & z_1 \cdot y_2 & z_1 \cdot z_2 \end{bmatrix} =$$

$$\begin{bmatrix} (x_2^1)^T \\ (y_2^1)^T \\ (z_2^1)^T \end{bmatrix} = [x_1^2, y_1^2, z_1^2]^T = [C_1^2]^T$$

- opposite perspective (2 wrt 1 given 1 wrt 2) is as simple as a matrix transpose!

.11

### Properties of Rotation Matrix

1.  $[C_2^1]^T C_2^1 = C_1^2 C_2^1 = I \Rightarrow C_1^2 = [C_2^1]^T = [C_2^1]^{-1}$
2.  $|([C_2^1]^T C_2^1)| = |C_2^1| |C_2^1| = |I| \Rightarrow |C_2^1| = \pm 1$  (+ for right hand coordinate system)
3. columns and rows of  $C_2^1$  are orthogonal
4. magnitude of columns and rows in  $C_2^1$  are 1

.12

## Rotation Matrix as Coordinate Transformation


- So far, rotation matrix  $C$  developed to describe orientation
- $C$  can also perform change of coordinates on vector

.13

## Rotation Matrix as Coordinate Transformation

- Consider a point  $P$  with location described as a vector in coordinate **frame {1}** as

$$\vec{P}^1 = \begin{bmatrix} u \\ v \\ w \end{bmatrix} = ux_1 + vy_1 + wz_1$$



.14

## Rotation Matrix as Coordinate Transformation

- With  $\vec{P}^1$  given, the location of point  $P$  can be described in coordinate **frame {2}** via

$$\begin{aligned} \vec{P}^2 &= \begin{bmatrix} \vec{P}^1 \cdot x_2 \\ \vec{P}^1 \cdot y_2 \\ \vec{P}^1 \cdot z_2 \end{bmatrix} = \begin{bmatrix} (ux_1 + vy_1 + wz_1) \cdot x_2 \\ (ux_1 + vy_1 + wz_1) \cdot y_2 \\ (ux_1 + vy_1 + wz_1) \cdot z_2 \end{bmatrix} \\ &= \underbrace{\begin{bmatrix} x_1 \cdot x_2 & y_1 \cdot x_2 & z_1 \cdot x_2 \\ x_1 \cdot y_2 & y_1 \cdot y_2 & z_1 \cdot y_2 \\ x_1 \cdot z_2 & y_1 \cdot z_2 & z_1 \cdot z_2 \end{bmatrix}}_{?} \underbrace{\begin{bmatrix} u \\ v \\ w \end{bmatrix}}_{?} \end{aligned}$$

.15

## Rotation Matrix as Coordinate Transformation

$$\begin{aligned} &= \underbrace{\begin{bmatrix} x_1 \cdot x_2 & y_1 \cdot x_2 & z_1 \cdot x_2 \\ x_1 \cdot y_2 & y_1 \cdot y_2 & z_1 \cdot y_2 \\ x_1 \cdot z_2 & y_1 \cdot z_2 & z_1 \cdot z_2 \end{bmatrix}}_{C_1^2} \underbrace{\begin{bmatrix} u \\ v \\ w \end{bmatrix}}_{\vec{P}^1} \\ &= C_1^2 \vec{P}^1 \end{aligned}$$

- $\Rightarrow \vec{P}^2 = C_1^2 \vec{P}^1$
- $C_1^2$  re-coordinatized vector written wrt frame 1 into frame 2 by a matrix-multiplication
- superscripts and subscripts help track/denote re-coordinatization

.16

## Rotation Matrix as Coordinate Transformation

Similarly, coordinate transformations can be performed opposite way as well


$$\begin{aligned}\vec{P}^2 &= C_1^2 \vec{P}^1 \\ \Rightarrow \vec{P}^1 &= [C_1^2]^{-1} \vec{P}^2 \\ &= [C_1^2]^T \vec{P}^2 \\ &= C_2^1 \vec{P}^2\end{aligned}$$

.17

## 4 Examples

### Example 1

Given  $C_b^a = \begin{bmatrix} 0.866 & 0 & 0.5 \\ 0.433 & 0.5 & -0.75 \\ -0.25 & 0.866 & 0.4330 \end{bmatrix}$  and frame  $a$ , sketch frame  $b$ .



.18

### Example 2

Frame 1 has been rotated away from frame 0 by  $30^\circ$  about  $z_0$ . Find  $\vec{r}^0$  given  $\vec{r}^1 = [0, 2, 0]^T$ .

.19

## 5 Summary

Summary

Rotation matrix can be thought of in three distinct ways:

1. It describes the orientation of one coordinate frame *wrt* another coordinate frame
2. It represents a coordinate transformation relating the coordinates of a point (e.g.,  $P$ ) or vector in two different frames of reference
3. It is an operator taking a vector  $\vec{p}$  and rotating it into a new vector  $C\vec{p}$ , both in the same system

\_\_\_\_\_.20

The End

\_\_\_\_\_.21