Lecture Sensor Technology EE 565: Position, Navigation and Timing


Lecture Notes Update on March 3, 2020

Aly El-Osery and Kevin Wedeward, Electrical Engineering Dept., New Mexico Tech In collaboration with Stephen Bruder, Electrical & Computer Engineering, Embry-Riddle Aeronautical University

Terminology

- Accuracy: Proximity of the measurement to the true value
- Precision: The consistency with which a measurement can be obtained
- Resolution: The magnitude of the smallest detectable change
- **Sensitivity:** The ratio between the change in the output signal to a small change in input physical signal. Slope of the input-output fit line.
- Linearity: the deviation of the output from a "best" straight line fit for a given range of the sensor


1



.2

.1

Accuracy vs Precision



.3

.4

Inertial Sensors — Bias Errors

- Bias often the most critical error
 - Fixed Bias b_{FB}
 - * Deterministic in nature and can be addressed by calibration
 - * Often modeled as a function of temperature
 - Bias Stability b_{BS}
 - * Varies from run-to-run as a random constant
 - Bias Instability b_{BI}
 - * In-run bias drift typically modeled as random walk

Bias Errors

$$\Delta f = b_{a,FB} + b_{a,BI} + b_{a,BS} = b_a$$
$$\Delta \omega = b_{g,FB} + b_{g,BI} + b_{g,BS} = b_g$$


Inertial Sensors — Scale Factor Errors

- Fixed scale factor error
 - Deterministic in nature and can be addressed by calibration
 - Often modeled as a function of temperature
- Scale Factor Stability s_a (accel) or s_g (gyro)
 - Varies from run-to-run as a random constant
 - Typically given in parts-per-million (ppm)

Scale Factor Errors

$$\Delta f = s_a f, \qquad \Delta \omega = s_g \omega$$

The scale factor represents a linear approximation to the steady-state sensor response over a given input range — True sensor response may have some non-linear characteristics



.5

.6


.7

Inertial Sensors — Misalignment

- Refers to the angular difference between the ideal sense axis alignment and true sense axis vector
 - a deterministic quantity typically given in milliradians

$$\Delta f_z = m_{a,zx} f_x + m_{a,zy} f_y$$
$$\Delta \omega_z = m_{a,zx} \omega_x + m_{a,zy} \omega_y$$

• Combining misalignment & scale factor



Inertial Sensors — Cross-Axis Response

- Refers to the sensor output which occurs when the device is presented with a stimulus which is vectorially orthogonal to the sense axis
- Misalignment and cross-axis response are often difficult to distinguish Particularly during testing and calibration activities

Inertial Sensors — Other Noise Sources

Typically characterized as additive in nature

- May have a compound form
 - white noise
 - * Gyros: white noise in rate \Rightarrow Angle Random Walk (ARW)
 - * Accels: white noise in accel \Rightarrow Velocity Random Walk (VRW)

- Quantization noise
 - * May be due to LSB resolution in ADC's
- Flicker noise
- Colored noise

Inertial Sensors — Gyro Specific Errors

- G-sensitivity
 - The gyro may be sensitive to acceleration
 - Primarily due to device mass assymetry
 - Mostly in Coriolis-based devices (MEMS)


$$\Delta \vec{\omega}_{ib}^{\ b} = G_g \vec{f}_{ib}^{\ b} a$$

- G²-Sensitivity
 - Anisoelastic effects
 - Due to products of orthogonal forces

Inertial Sensors — Accel Specific Errors

- Axis Offset
 - The accel may be mounted at a lever-arm distance from the "center" of the Inertial Measurement Unit (IMU)
 - $\ast\,$ Leads to an " $\omega^2 r$ " type effect

$$\Delta f_x = \omega_y^2 \Delta x + \omega_z^2 \Delta x = \left(\omega_y^2 + \omega_z^2\right) \Delta x$$



Inertial Sensors — Sensor Models

• Accelerometer model

$$\vec{f}_{ib}^{b} = \vec{f}_{ib}^{b} + \Delta \vec{f}_{ib}^{b} = \vec{b}_{a} + (\mathcal{I} + M_{a})\vec{f}_{ib}^{b} + \vec{w}_{a}$$
(1)

• Gyro Model

$$\tilde{\vec{\omega}}_{ib}^{\ b} = \vec{\omega}_{ib}^{\ b} + \Delta \vec{\omega}_{ib}^{\ b} = \vec{b}_g + (\mathcal{I} + M_g) \vec{\omega}_{ib}^{\ b} + G_g \vec{f}_{ib}^{\ b} + \vec{w}_g$$
(2)

• Typically, each measures along a signle sense axis requiring three of each to measure the 3-tupple vector

.10

.11

.8

.9