## **Review for Second Exam**

- 1. C Programming
  - (a) Setting and clearing bits in registers
    - PORTA = PORTA | 0x02;
    - PORTA = PORTA & ~0x0C;
  - (b) Using pointers to access specific memory location or port.
    - \* (unsigned char \*) 0x0400 = 0xaa;
    - #define PORTX (\* (unsigned char \*) 0x400) PORTX = 0xaa;
  - (c) Interrupts
    - i. Interrupt Vectors (and reset vector)
      - How to set interrupt vector in C
    - ii. How do you enable interrupts (specific mask and general mask)
    - iii. What happens to stack when you receive an enabled interrupt
    - iv. What happens when you leave ISR with RTI instruction?
    - v. What setup do you need to do before enabling interrupts?
    - vi. What do you need to do in interrupt service routine (clear source of interrupt, exit with RTI instruction)?
    - vii. How long (approximately) does it take to service an interrupt?
- 2. Timer/Counter Subsystem
  - (a) Enable Timer
  - (b) Timer Prescaler
    - How to set
    - How it affects frequency of timer clock
  - (c) Timer Overflow Interrupt
  - (d) Input Capture
  - (e) Output Compare
  - (f) How to enable interrupts in the timer subsystem
  - (g) How to clear flags in the timer subsystem

- 3. Real Time Interrupt
  - (a) How to enable
  - (b) How to change rate
  - (c) How to enable interrupt
  - (d) How to clear flag
- 4. Pulse Width Modulation
  - (a) How to get into 8-bit, left-aligned high-polarity mode
  - (b) How to set PWM period (frequency)
  - (c) How to set PWM duty cycle
  - (d) How to enable PWM channel